



AP 3 POE POE DC


1. POE AP WEB



2. POE AP WEB



3. DC AP WEB




DC

AP

AP

DC

1. AC WEB



2. AC Console




Console RJ45

RS232 USB



AC	AP	WEB	192.168.110.1
admin	PC	IP	192.168.110.2
			255.255.255.0

<http://192.168.110.1>



1. Console

COM	COM
9	COM
COM	USB
COM	RS232
AC	AP
Console	“ Console ”
AP	Telnet
	WEB

